

RADIUS TACTILE - REPLACEABLE

(WET-SET)

Replacement Procedure

Be sure to read and understand all of these instructions before you begin.

- A.** Lift the existing composite bolt cap from each anchor location on the ADA Replaceable Tactile unit (ADAREP) with a flat head screw driver.
- B.** Remove the existing 1/2" x 1 1/2" heavy duty steel bolt & washer from each anchor location on the ADAREP unit with a ratchet. Save & reuse.
- C.** Tap around all sides of the ADAREP unit and across the middle with a rubber mallet, working in a grid pattern.
- D.** Pry the existing ADAREP unit from the concrete ramp with a small prybar, working around the edges until it can be lifted cleanly away.
- E.** Be sure to remove all small debris and dust from the existing impression in the concrete ramp.
IMPORTANT: Be careful not to get debris into anchor locations.
- F.** Replace new ADAREP unit into impression in concrete ramp. Lightly tamp down the ADAREP unit with a rubber mallet and a piece of wood. Continue this process until the ADAREP unit is set firmly into existing impression in concrete ramp.
IMPORTANT: Avoid striking the ADAREP unit directly.
- G.** Bolt existing 1/2" x 1 1/2" heavy duty steel bolt & washer back into each anchor location on new ADAREP unit.
- H.** Snap a new composite bolt cap provided, into each anchor location on the ADAREP unit. The ADAREP unit is ready for pedestrian traffic immediately after installation is complete.



U.S. Patent
No. 7,779,581

View additional photos, drawings and specifications
on our website: www.adatile.com.
Call (800) 372-0519 with any questions.